

SEM 7810 Extension

CAUTION

IMPROPER INSTALLATION OR REGULATION MAY RESULT IN PERSONAL INJURY OR PROPERTY DAMAGE. FOLLOW ALL INSTRUCTIONS CAREFULLY. FOR QUESTIONS, CALL LCN AT 800 - 526 - 2400

1. Remove contact plate locking screw.
2. Pull contact plate away from armature base. (Caution: the 2 plastic spacer disks on the contact plate may fall out.)
3. Insert ball link into armature base. Reinsert and tighten locking screw.
4. Insert contact plate with plastic spacer disks in place into connector link. Reinsert and tighten screw.
5. Attach extension link(s) as needed. (Note: Using just the ball link and connector link will create a 1 ½" link. Extension Links are available in different lengths and can be combined together to achieve the desired length.)
6. Attach contact plate and connector link assembly to extension link (s). Align contact plate with magnet and tighten all set screws.

